













Knobka GZ-CRPA
 Knobka GZ-CRPA
 Gomb fogantyú GZ-CRPA
 Buton GZ-CRPA



 mm	 mm			
		chrom, bílý kryštál chróm, biely kryštál króm, fehér kristály crom, cristal alb	chrom, černá kryštál chróm, čierna kryštál króm, fekete kristály crom, cristal negru	mosaz, bílý kryštál mosadz, biely kryštál sárgaréz, fehér kristály alamā, cristal alb
20	33	GZ-CRPA20-01	-	-
25	37	GZ-CRPA25-01	-	-
30	44	GZ-CRPA30-01	GZ-CRPA30-A1	GZ-CRPA30-03
40	55	GZ-CRPA40-01	-	-
ZnAl, sklo ZnAl, sklo ZnAl, üveg ZnAl, sticliā				

Knobka GZ-CRPB
 Knobka GZ-CRPB
 Gomb fogantyú GZ-CRPB
 Buton GZ-CRPB



 mm	 mm			
		chrom, bílý kryštál chróm, biely kryštál króm, fehér kristály crom, cristal alb	chrom, černá kryštál chróm, čierna kryštál króm, fekete kristály crom, cristal negru	mosaz, bílý kryštál mosadz, biely kryštál sárgaréz, fehér kristály alamā, cristal alb
20	26	GZ-CRPB20-01	-	-
25	28	GZ-CRPB25-01	GZ-CRPB25-A1	-
30	30	GZ-CRPB30-01	GZ-CRPB30-A1	GZ-CRPB30-03
40	38	GZ-CRPB40-01	GZ-CRPB40-A1	-
ZnAl, sklo ZnAl, sklo ZnAl, üveg ZnAl, sticliā				